

SC Male Connector Clamp/Solder Attachment For RG213, RG214, RG8, RG9, RG225, RG393

## **TECHNICAL DATA SHEET**

## PE4520

Configuration	
Connector	SC Male
Connector Specification	MIL-C-39012
Connector Interface Type	RG213,RG214,RG8,RG9,RG225,RG393
Cable Attachment Method (Shield/Contact) Body Style	Clamp/Solder Straight
Electrical Specifications	
Impedance, Ohms	50
Mechanical Specifications	
Temperature	
Operating Range, deg C	-65 to +165
Size	
Length, in [mm]	1.5 [38.1]
Width/Dia., in [mm]	0.8 [20.32]
Weight, Ibs [g]	0.11 [49.9]
Connector	
Туре	SC Male
Contact Material and Plating	Silver
Contact Plating Specification	QQ-S-365
Coupling Nut Material and Plating	Brass, Nickel
Body Material and Plating	Brass, Nickel
Dielectric Type	Teflon
Compliance Certifications (visit www.Pasternack.or	
RoHS Compliant	Yes
Plotted and Other Data	
Notes:	Values at 25 °C, sea level

Click the following link (or enter part number in "SEARCH" on website) to obtain additional part information including price, inventory and certifications: SC Male Connector Clamp/Solder Attachment For RG213, RG214, RG8, RG9, RG225, RG393 PE4520


The information contained in this document is accurate to the best of our knowledge and representative of the part described herein. It may be necessary to make modifications to the part and/or the documentation of the part, in order to implement improvements. Pasternack reserves the right to make such changes as required. Unless otherwise stated, all specifications are nominal.

Pasternack Enterprises, Inc. • P.O. Box 16759, Irvine, CA 92623 **Phone:** (866) 727-8376 or (949) 261-1920 • **Fax:** (949) 261-7451 Sales@Pasternack.com • Techsupport@Pasternack.com






MATERIALS	BRASS NICKEL PLATED	CT SILVER PLATED	TOR PTFE	
	ворү	CONTACT	<b>NSULATOR</b>	



## ASSEMBLY PROCEDURES

1. SLIDE CLAMP NUT (1) & GASKET (2) OVER CABLE. STRIP CABLE AS SHOWN. DO NOT NICK BRAID WHILE CUTTING JACKET. TAPER END OF BRAID TO PERMIT ASSEMBLY OF BRAID CLAMP (3) SLIDE BRAID CLAMP(3) OVER BRAID & SEAT AGAINST CABLE.



2. FORM BRAID OVER CLAMP NUT (3). TRIM BRAID BACK TO SHOULDER. CUT DIELECTRIC TO DIMENSION SHOWN. DO NOT NICK CENTER CONDUCTOR. SOLDER CONTACT TO CENTER CONDUCTOR. REMOVE EXCESS SOLDER. DO NOT OVER HEAT DIELECTRIC. INSERT CABLE ASSEMBLY INTO BODY & TIGHTEN.

.175

.050

